

X-FLAP AFTERMARKET EXHAUST VALVE CONTROLLER - TM

Ver.0.0.1

The X-FLAP Aftermarket Electronic Valve Controller is specifically designed for vehicles requiring the installation of aftermarket exhaust valves. The standard configuration supports single-valve control and can be expanded to dual-valve synchronized control via an optional dual-valve extension harness. The controller supports three operating modes: ON (Fully Open), OFF (Fully Closed), and AUTO (12V Trigger Linkage), which can be switched instantly via a smartphone APP or remote control to establish a comprehensive electronic valve control system.


*Optional valve seats (51mm/2", 63mm/2.5", 76mm/3") are available for purchase to be welded onto exhaust piping such as the rear muffler or side pipes.

*An optional direct-drive valve motor is available. The motor body adopts standard BMW electronic valve mounting specifications; if the factory motor is damaged, it can also serve as a replacement and operate independently with this controller, without the need to use the factory wiring.

► CONTENTS

SINGLE VALVE



X-FLAP TM-EA5 SW16017-03



► OPTIONAL

OPTIONAL KIT

The valve seat includes fixing bolts and a return spring. ►



*The valve seats are weld-on type.

*The motor mounting points are compatible with standard BMW specifications; actual installation depends on the vehicle configuration.

DUAL-VALVE EXTENSION HARNESS KIT



*For dual-valve control, please purchase the Dual-Valve Extension Harness Kit separately.


Valve Signal Cable (Hanging Card Packaging)
SW13205-00

► WIRING INSTRUCTIONS

- This product includes an independent power harness; connecting to the interior fuse box ACC (+12V) is recommended.
- The standard configuration supports single-valve control; for dual-valve synchronized control, please purchase the Dual-Valve Extension Harness Kit separately.
- If equipped with the optional dual-valve extension harness, both left and right valve signal cables feature pre-wired power plugs; connect power to one side only during installation.
- The waterproof main unit must be secured in a higher position on the chassis to prevent impact or water damage.
- Secure the wiring harness clear of drive shafts, suspension links, high-temperature exhaust piping, or any areas prone to tension or abrasion.
- AUTO mode requires the yellow trigger wire. If disconnected, the valve remains OFF in AUTO mode.
- In OFF (Fully Closed) mode, drive only at low RPM and low load. Avoid heavy acceleration to prevent high backpressure, ECU errors, or vehicle damage.


► INSTALLATION

SINGLE VALVE



► INSTALLATION

DUAL VALVE



► APP INSTRUCTIONS

This product can be used with the APP.



APP Name: X-FLAP


Device: X-FLAP_OTA (Exhaust)

Password: 1111

Requires iOS 17.0 or later / Android 5.0 or later.



Download Link



► OPERATION INSTRUCTION


Settings Mode




Controller Model

Home

VALVE STATE




Fully Open



Fully Closed

STATE: AUTO
[ON / OFF]



AUTO Mode

+12V Input : AUTO-ON


No Input : AUTO-OFF



▶ DEFAULT & DETAILED SETTINGS

DEFAULT

App configures startup valve status. Default is LST (Memory Mode): retains status from last shutdown. Startup status can be fixed to ON, OFF, or AUTO.




▶ REMOTE CONTROL PAIRING


Open App to
Settings



Tap "PAIRING"




Tap "REMOTE CONTROL"



YES



Complete



Long press the
remote ON/OFF
button until the red
LED flashes once.

*Ensure ACC power is ON.

*If "PAIRING FAILED" appears, please retry.



Address: NO.163 Fan-Hwa Road, Chin-Hsin Village, Hsiu-Shui, Chang Hwa, TAIWAN
Tel: +886-4-7681140 Fax: +886-4-7698587 E-mail: info@autojaw.com

Copyright 1999-2026 AUTO JAW CO,LTD ALL Rights Reserved.

