


## FEATURES


- **Plug and play. No need further cabling.**
- **Equipped with fuse for electronic protection.**
- **Various lighting mode available. Driver would have protection from car accident.**
- **All mode display. Showing off at the gathering party.**
- **Parking mode. For short time parking. Let other cars to pay more attention to your car.**

## CONTENTS




(the above pictures may be different from reality and they are only for reference)

## INSTALLATION DRAWING



This Female connector connects original Male connector



This 2PIN Female connector connects 2PIN Male connector of power supply harness

This Male connector connects Female connector of taillight

Taillight

△ Every car's taillight are all different. Drawing is just for reference.



△ If it needs to take off the backplate, you might need the help from professionals.

## NOTICE

- **Warrenty does not include wrong installation. Product or car are damaged because of inappropriate use or installation, Auto Jaw will not compensate.**
  - **Please install at well ventilated place to avoid Carbon Monoxide poisoning**
  - **Do not damage the wire skin. If the wire skin is damaged it would cause short circuit and fire.**
  - **Please use tape to stick all the cable in appropriate place avoid any inconvenience.**
  - **Do not use this product during driving. It might distract the driver and cause accident.**
  - **Any questions for the installation please consult with stores or professionals.**
  - **This product is only available for DC 12V cars. Other voltage would not be available.**
- Please do not modify this product.**
- **Do not install this product at high temperature place or wet place to avoid any unexpected damage**
  - **Do not give too heavy force on the product after installation.**










## OPERATION INTERFACE

Remote control







Mode in cycle. Equipped with memory function. Will remain at the last using mode when restart.

## FUNCTION

All Taillight Status		Trigger on the car	Trigger on the remote	Available Mode	Notice
 Small Light (Red)	 Small Light	Turn on small light	 SET Button	7	Set up when the small light is on.
 Parking Light (Yellow)	 Parking Light	Turn on parking light		8	Set up when the parking light is on.
 Brake Light (All on)	 Brake Light	Step on the brake		4	Set up when the brake light is on. Suggest two people to work on the set up so one person can hold the brake.
 Direction Signal (Single one)	 Direction Signal	Turn on direction signal		4	Need to open the ACC and turn on the signal light while set up.

- ⚠ If continuous brake within 8 sec the brake light will not fast flash. It will hold the light on as original setting. We design this to avoid causing trouble with the driver behind.
- ⚠ Some function may not be available if the car's voltage and current are insufficient.

## SPECIAL FUNCTION

Press the button	Time	Display	Release	Explain
	Long press for 5 sec	Open long parking mode. After blink for 1 hour, it will start eco mode. 	Press SET or POWER can release the parking mode Parking Light/ Signal Light/ Brake Light all can release the Eco Mode/ Parking Light	After parking you can switch on the parking mode and the taillight will start display. It will get attention on the street. Keep your car safe.
	Long press for 5 sec	Open display mode. It will show the taillight display. 	Press SET or Power can release the Display Mode.	This mode can display at different occasion and can be used as warning.

## TROUBLESHOOTING

Symptom	Cause	Troubleshooting
Taillight cannot be turned on	Fuse damaged	Check fuse
	Power supply is defective	Check if the power supply is well connected
Remote control cannot use	Bluetooth is not paired up. Signal is not found	Go back to shops and paired up the bluetooth
Taillight cannot be controlled	Initial setting did not turn on POWER	Check wires if they are connecting to the right place
Taillight cannot be controlled	Remote/ Control Box is not switch on the POWER	Please check manual for more reference
	Initial setting did not turn on POWER	Please check manual for more reference



SHADOW AUTO TLC Manual

Factory : Auto Jaw Co., Ltd

Tele : 04-7681140 Fax : 04-7698587

Address : No. 348 Fan-Hwa Road, Chin-Hsing Village,

Hsiu-Shui, Chang Hwa, Taiwan R.O.C

Website : www.shadowmotor.com.tw



Shadowmeter



著作權 丞興股份有限公司 本文禁轉

Made In Taiwan